


KONE RemoteCall™ with fixed source floor

KONE RemoteCall with fixed source floor is a special feature in the KONE RemoteCall application that predefines the source floor so the user selects only the destination floor. The application runs on iPad tablets and is typically used by building receptionists or passengers. It can also be located in the main lobby, elevator lobby, or next to the conference rooms to give quick and convenient elevator destination calls from that floor.



KEY FEATURES

Improved People Flow

- Receptionists can quickly call an elevator for visitors and guide them to the correct elevator car – no need for the host to collect visitors from the lobby

Shorter waiting time

- Reduces waiting times and eases lobby congestion

User friendly

- Can be installed on pedestal or desk stand
- The clear, intuitive interface is easy to use

- Can be used as temporary DOP – during special events extra devices can easily be placed next to elevators.


- The application is easy to download from the Apple AppStore

Access control

- Improves access control, with only permitted destination floors listed

Easy to use

When the KONE RemoteCall for fixed source floor application is opened, the scrolling list view of the destination floors is directly visible. Just one click to the destination floor and the call is made. The identification letter of the allocated elevator is displayed on the screen.



Easy to configure

The departure floor is set in two simple steps:

1. Go to iPad settings and reset the fixed floor of the RemoteCall application.
2. Open the RemoteCall application. You will be asked to set the floor from which calls are made from.



www.kone.com